

DOTD Statewide ATMS.now System Layout


LADOTD HQ
Administrative Workstations

Traffic Operations
Administrative
Workstations

ITS
Administrative
Workstations

LADOTD Statewide ATMS.now
Database Backup server
(Maintained by LADOTD ITS)
H27000ATMSNOW
10.90.56.75

- State Level Users
- Full Access to all Dist. Server
 - View/Edit Privledges to all Dist
 - Full System Status to all Dist
 - Access Statewide ATMS.now Backup



- District/Local Level Users
- Access Restricted to Own Dist
 - View/Edit Privileges within Dist
 - Full System Status to own Dist

Regional server #1
District 04, 08
Hosted District 04
R04-08ATMSNOW
10.94.102.27

Regional server #2
District 05, 58
Hosted District 05
R05-58ATMSNOW
10.95.102.27

Regional server #3
District 03, 07
Hosted District 07
R07-03ATMSNOW
10.97.102.27

Regional server #4
District 61, 62
Hosted District 61
R61-62ATMSNOW
10.91.102.27

Regional server #5
District 02, 02H
Hosted District 02
R02-02HATMSNOW
10.92.120.189

